

TRIPLE TREE INSTALLATION INSTRUCTIONS

2005 & Down Dyna Wide Glide Softail Standard 5° 41mm

This product is designed for use on a trike or a bike with a sidecar. Please read instructions fully before starting installation. Refer to your bikes service manual. Warning - Front end performance is a critical safety item. Triple trees should be installed by a qualified service technician.

- 1. After the trike rear end is installed. Put the bike in gear and place a block of wood behind the rear wheels. Jack the front of the trike up enough to get the wheel off of the ground.
- 2. Remove the front caliper. Hang off to the side. Do not remove the brake line from the caliper.
- 3. Place a heavy blanket over the gas tank as the handle bars will be placed on the gas tank.
- 4. Remove the front wheel and front fender. Remove headlight hang off to the side. Remove handle-bars and place on the blanket. Do not disconnect brake lines, cables or wires.
- 5. Remove fork tubes. Remove the triple tree.
- 6. Remove the plastic from around the bearing on the new triple tree. Clean and repack the upper bearing with grease or replace if necessary.
- 7. Install lower triple tree in neck, install the jam nut (C.) on the triple tree stem. Tighten the jam nut. The neck bearings need to have more pre-load as a trike. Make sure that the triple tree will turn. If the triple tree will not turn loosen the jam nut (C.) a little.
- 8. Install top of new triple tree. Install top triple tree nut. Do not tighten yet.
- 9. Install fork tubes and fork tube bolts, tighten fork tube bolts.
- 10. Tighten the top triple tree nut.
- 11. Tighten fork tube pinch bolts (A.).
- 12. Install handle bars, headlight, fender, wheel and caliper.
- 13. Refer to service manual for torque specifications.



Installation of raked triple tree may change the position of the headlight mount, please check an adjust headlight beam to safe angle.



TRIPLE TREE INSTALLATION INSTRUCTIONS

2005 & Down Dyna Wide Glide Softail Standard 5° 41mm

